



Anti-Slip Commercial

DIRECTIONS FOR USE ON TILES

PREPARATION:

1. Thoroughly clean the area to be treated and ensure it is free from dirt and grease.
2. Test product on an inconspicuous area to decide the number of applications required and to ensure the surface will not be adversely change the treated area (This area needs to be the same substrate to ensure the product will not adversely effect the substrate)

APPLICATION:

1. Use undiluted. Pour product into a bucket or roller tray,Apply Anti Slip Commercial to the surface evenly using soft brush, sponge applicator, natural bristle, broom, or sponge Leave for two to three minutes. **Do not allow to dry;**
2. Apply second application of Anti Slip Commercial, as above. Leave for two to three minutes. **Do not allow to dry;**
3. Reapply, if necessary, and again allow to stand for a similar time;
4. When the desired degree of slip-resistance has been achieved, wash excess product from the surface with detergent. **Applicator must ensure no product is left behind and allowed to dry as this will stain the surface.**
5. Rinse with clean water;
6. Finish with a damp mop or vacuum dry.

Prepared by

Viroseal Pty Ltd

www.virosealaustralia.com