

# Anti Slip



## DIRECTIONS FOR USE ON TILES

### PREPARATION:

1. Thoroughly clean the area to be treated and ensure it is free from dirt and grease;
2. Tape, cover/shield any edges or surfaces not to be treated;
3. Test product on an inconspicuous area to decide the number of applications required;
4. **Do not pour product direct from bottle onto surface;** use Bucket or suitable container, and appropriate applicator Brush/squeegee.

### APPLICATION:

1. One litre of "Anti Slip" treats up to ten (10) square metres in up to three applications (ie. 1/3 litre per application). Spread "Anti Slip" evenly over surface using brush, natural bristle broom, or sponge squeegee;
2. Leave for two to three minutes.  
**Do not allow to dry at any stage during application;**
3. Reapply, if necessary, and again allow to stand for a similar time, not allowing product to dry;
4. Reapply, if necessary, as before;
5. When the desired degree of slip-resistance has been achieved, wash excess product from the surface with detergent.
6. Rinse with clean water;
7. Finish with a damp mop or vacuum dry.

**VIROSEAL PTY LTD**

ABN: 28 133 920 804

Unit 2/23, Gardens Drive, Willawong, Qld. 4110

Phone: 07 3276 1033 Fax: 07 3276 1022

Bob Mob: 0417 784 558

Tim Mob: 0409 998 858

E: [tim@virosealaustralia.com](mailto:tim@virosealaustralia.com)

E: [bob@virosealaustralia.com](mailto:bob@virosealaustralia.com)

[www.virosealaustralia.com](http://www.virosealaustralia.com)

